



Sennheiser Assisted Hearing Pendant User Guide

Setting the receiver to the frequency of the transmission system

You can set the receiver to the frequency of the transmission system yourself or have the frequency preset by your Sennheiser partner.

1

Put the receiver on.




2

Press the channel selection button.



Until you have found the frequency of your transmission system.



3

On the receiver, the channel indicator



can light up as follows:

- | **Left** General audio
- | **Right** Audio description
- || **Left & Right** split between General in one ear and AD in the other

Please ask a member of staff if you require any further assistance.